FAVORIT 40740

Dishwasher

User Instructions

Downloaded from www.Manualslib.com manuals search engine

Dear customer,

Please read these user instructions carefully.

Please observe the safety instructions on the first few pages of these user instructions! Please keep these user instructions for later reference. Pass them on to any subsequent owner of the appliance.

The warning triangle and/or specific words **(Warning!, Caution!, Important!)** are used to highlight instructions that are important for your safety or for the function of the appliance. It is imperative that these instructions are observed.

☞ This symbol or numbered instruction steps lead you step by step through the operation of the appliance.

Next to this symbol you receive additional information and practical tips on using the appliance.

Tips and instructions for the economical and environmentally conscious use of the appliance are marked with a clover leaf.

In the event of a malfunction, these operating instructions contain information on how to rectify faults yourself, see the "What to do, if..." section.

If these instructions are insufficient, please contact your AEG Service Force Centre.

In this respect please read the chapter "Service & Spare Parts".

Printed on paper manufactured with environmentally sound processes. He who thinks ecologically acts accordingly ...

Downloaded from www.Manualslib.com manuals search engine

CONTENTS

Operating Instructions 5

Safety Instructions 5

Disposal 7

Economical and Ecological Dishwashing 7

Appliance Features and Control Panel 8
Control panel 9

Prior to using for the first time 10
Water softener 10
Setting the water softener 11
Special salt for the water softener 12
Setting the amount of special salt to be added 12
Adding special salt 13
Rinse aid 14
Activating/deactivating the inflow of rinse aid 14
Adding rinse aid 15
Adjusting Rinse Aid Dosing 16

In Daily Use 17
Loading Cutlery and Dishes 17
Loading Cutlery 18
Loading Pans, Frying Pans and Large Plates 19
Loading Cups, Glasses and Coffee Services 21
Adjusting the Height of the Upper Basket 22
Filling with Detergent 23
Use of "3 in 1"/ Combi Detergent Tablets 24
Concentrated Detergent 25
Detergent tablets 25
Selecting the Wash Programme (Programme Table) 26
Starting a wash programme 27
Changing / interrupting / cancelling a wash programme 27
Setting or changing the start delay 28
Load Sensing – Sensor Logic 29
Switching Off the Dishwasher 29
Emptying the Dishwasher 29

Downloaded from www.Manualslib.com manuals search engine

Care and Cleaning 30
Cleaning the Filter 30

What to do, if 32
...Error messages are displayed. 32
...there are problems with the operation of the dishwasher. 34
...the wash results are not satisfactory. 34

Technical Data 35

Notes for Test Institutes 36

Installation and Connection Instructions 37

Installing the Dishwasher 37
Built-Under Dishwasher 37
Free-Standing Appliances 37

Connecting the Dishwasher 39
Water Connection 39
Permitted water pressure 39
Connect the inlet hose 39
Water drain 41
Leak Prevention System 42
Electrical Connection 43
Connections 44

Guarantee Conditions 45

Service and Spare parts 47

Downloaded from www.Manualslib.com manuals search engine

OPERATING INSTRUCTIONS

⚠ Safety Instructions

The safety aspects of AEG electrical appliances comply with accepted technical standards and the German Appliance Safety Law. Nevertheless, as a manufacturer we consider it our obligation to make you aware of the following safety information:

Installation, Connection and Placing into Operation

- The dishwasher may only be transported upright.
- Check the dishwasher for transport damage. Do not in any circumstances connect an appliance that is damaged. In the case of damage, please contact your retailer.
- Before installing the appliance, ensure that the nominal voltage and type of supply on the rating plate match that of the supply where the appliance is to be installed. The fuse rating is also to be found on the rating plate.
- For information on how to correctly install and connect up your dishwasher, please read the "Installation" section. Adaptors / connectors and extension cables must not be used.

Child Safety

- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Keep all packaging away from children.
- Keep all detergents in a safe place out of children's reach.
- The water in your dishwasher is not suitable for drinking. If there are still remnants of detergent in the appliance, there is a risk of burns!
- When disposing of an old appliance, cut off the power supply cable and remove any door catches, to prevent young children being trapped inside.

General Safety

- Repairs to the dishwasher are only to be carried out by qualified service engineers. Improper repairs can give rise to significant hazards for the user. If your appliance needs repairing, please contact your local AEG Service Force Centre.

Downloaded from www.Manualslib.com manuals search engine

- Never place the dishwasher in operation if the mains cable, water inlet or drain hose is damaged; or the control panel, work top or plinth area is damaged such that the inside of the appliance is freely accessible.
- If the mains lead is damaged, or is to be replaced for a longer lead, the cable (obtainable from AEG Service Force) must be replaced by a service engineer authorised by AEG.
- Never unplug the appliance by pulling on the cable, always pull the plug.
- Additions or modifications to the dishwasher are not permitted for safety reasons.
- Ensure that the door of the dishwasher is always closed when it is not being loaded or unloaded. In this way you will avoid anybody tripping over the open door and hurting themselves.
- Long bladed knives stored in an upright position are a potential hazard.
- Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.
- When finished loading or unloading, close the door as an open door can be a hazard.

Correct Use

- Only wash household dishes using the dishwasher. If the appliance is used for other purposes, or is used incorrectly, the manufacturer cannot accept any liability for any damage caused.
- Only use detergents specifically designed for use in domestic dishwashers.
- Do not put any solvents in the dishwasher. There is a risk of an explosion!
- The anti-flood system provides dependable protection against damage due to leaks. For this system to function correctly, the following preconditions must be met:
  - The appliance must remain connected to the mains even when it is switched off.
  - The dishwasher must be correctly installed.
  - Always shut off the water supply at the tap when the dishwasher is not to be used for longer periods, e.g. when you are away on holiday.
- Do not sit or stand on the open door, the appliance may tip over.

Downloaded from www.Manualslib.com manuals search engine

- In the event of a fault, first close the tap, then switch off the appliance and unplug it from the mains. If the appliance is permanently wired to the mains: remove the fuse.

Disposal

Disposing of the Packaging Material

Dispose of the dishwasher packaging material correctly. All the packaging materials used are harmless to the environment and can be recycled.

- Plastic parts are marked with standard international abbreviations:
  - >PE< for polyethylene, e.g. sheet wrapping material
  - >PS< for polystyrene, e.g. padding material (always CFC-free)
  - >POM< for polyoxymethylene, e.g. plastic clips
- Cardboard packaging is manufactured from recycled paper and should be deposited in the waste paper collection for recycling.

Disposal of Old Appliances

When disposing of old appliances, remove the plug and ensure that any locks or catches are removed to prevent young children becoming trapped inside.

Use an authorised disposal site.

Economical and Ecological Dishwashing

- Ensure that the water softener is correctly adjusted.
- Do not pre-rinse dishes under running water.
- When you wash a small load, the load sensor calculates the amount of water necessary and shortens the programme. It is more economical to always wash with a full load.
- Select the wash programme to suit the nature and degree of the soiling on the dishes.
- Do not use more detergent, special salt or rinse aid than is recommended in these operating instructions and by the detergent manufacturer.

Downloaded from www.Manualslib.com manuals search engine

Appliance Features and Control Panel



Downloaded from www.Manualslib.com manuals search engine

Control panel



Water softener and function button: In addition to the wash programme marked, it is also possible to adjust the dishwasher's water softener using a combination of these buttons.

The 3 lights of the **multidisplay** can indicate:

- the current stage of the selected wash programme.
- which fault has occurred in the dishwasher.



Control indicators indicate the following:

	Refill with salt
	Refill with rinse aid

The control indicators never light up while a wash programme is running.

Downloaded from www.Manualslib.com manuals search engine

Prior to using for the first time

Prior to using for the first time, remove all the clips with which the baskets are secured for transport.
Then perform the following steps:

☞ **1.** Adjust the water softener

2. Fill the water softener with water and special salt

3. Fill the rinse aid dispenser with rinse aid

Special salt and rinse aid must not be added if you use 3-in-1 detergent tablets.

Water softener

To avoid scale deposits on the dishes and in the dishwasher, the dishes must be washed with soft water, i.e. water with a low lime content. The dishwasher therefore has a built-in water softener, in which tap water with a hardness of 4°d (German degree) and harder is softened with the aid of special salt.

Your water supplier will be able to inform you about the hardness and hardness range of the water in your area.
The water softener can be set manually using the water hardness switch; it can also be set electronically using the buttons on the control panel.

Water hardness			Adjusting the hardness setting		Number of flashes
in °d[1]	in mmol/l[2]	Range	Manually	Electronically	
51 - 70	9,0 - 12,5	IV	1	10 [3]	10
43 - 50	7,6 - 8,9			9	9
37 - 42	6,5 - 7,5			8	8
29 - 36	5,1 - 6,4			7	7
23 - 28	4,0 - 5,0			6	6
19 - 22	3,3 - 3,9	III	0*	5	5
15 - 18	2,6 - 3,2			4*	4
11 - 14	1,9 - 2,5	II		3	3
4 - 10	0,7 - 1,8	I/II		2	2
under 4	under 0.7	I		1 no salt necessary	1

Downloaded from www.Manualslib.com manuals search engine

1) (°d) German degree, measure of the hardness of water
2) [mmol/l] millimol per litre, international unit for the hardness of water
3) On this setting the length of the wash programme may be slightly longer.
*) factory setting

Setting the water softener

Using the table as a guide, adjust the water softener to that which corresponds to the hardness of the water in your area:

☞ The dishwasher must be switched off.



Setting manually:

1. Open the dishwasher door.
2. Remove the lower basket from the dishwasher.
3. Turn the hardness range switch to 0 or 1 (see table).
4. Replace the lower basket.

Setting electronically:

1. Press the ON/OFF button.
   The ON/OFF button's LED will illuminate.

ⓘ If other indicators are also illuminated, this means that a wash programme has been started. The wash programme must be cancelled (RESET):
Press function buttons **2** and **3** simultaneously for approx. 2 seconds.
All other indicators will go out.

2. Press function buttons **2** and **3** simultaneously and keep them pressed.
   The LED indicators for function buttons 1 to 3 will flash.
3. Press function button **1**.
   The LED indicator for function button **1** will flash.
   The LED indicator for the end of the wash programme will flash simultaneously:
   - The number of times that the LED indicator for the end of the wash programme flashes corresponds to the hardness setting.
   - This sequence of flashes is repeated many times, with a 3 second pause in between.
4. Pressing function button **1** increases the hardness setting by 1. (Exception: hardness setting 1 follows hardness setting 10).
5. When the hardness setting is correct, press the ON/OFF button.
   The hardness setting is now saved.

Downloaded from www.Manualslib.com manuals search engine

Special salt for the water softener

If the water hardness in your area is less than 4 °d, then the water in your dishwasher does not need to be softened and you do not need to use special salt or salt substitute.

Water can be softened in one of two ways:

- If you are using dishwasher detergent that already contains salt substitute, the detergent only is put into the detergent compartment.
  - In this case the water softener must **manually be set to 0 and electronically to 1** to ensure that no special salt is added.
- If you are using dishwasher detergent and special salt separately, the special salt is to be put into the salt container.
  - In this case the water softener must **manually be set to 0 and electronically to between 2 and 10** (depending on the water hardness in your area) to ensure that the special salt is dispensed from the salt container.

Only use special salt intended for dishwashers. Never fill the salt supply container with different types of salt (e.g. cooking or table salt) or detergent. This would destroy the water softener.
Prior to filling with salt, please check each time that you really do have a packet of special salt in your hand.

Setting the amount of special salt to be added

Some appliances are equipped with an additional **3 in 1** function.
If you use 3-in-1 dishwashing tablets and select the **3 in 1** function together with the programme, the inflow of special salt does not have to be deactivated (see "**3 in 1** function").

☞ **1.** Set the water softener manually and electronically to the desired water hardness:

Manual setting	Electronic setting	Number of flashes	Addition of special salt
0	1	1	Do not add special salt.
0 - 1	2-10	2 to 10	Addition of special salt via salt container (factory setting)

If the water softener is electronically set at "1" for the purpose of using detergent that includes special salt, the special salt indicator is deactivated.

Downloaded from www.Manualslib.com manuals search engine

Adding special salt

If you are using dishwasher detergent and special salt separately, add the special salt:

- Before using the dishwasher for the first time.
- When the indicator for special salt ⥁ is illuminated on the control panel.

☞ **1.** Open the door, remove the lower basket.

2. Undo the lid on the salt container by turning it anticlockwise.

3. When using for the first time: fill the salt container with water.

4. Place the funnel supplied on the container opening.
Fill the container with salt through the funnel; the capacity of the container is approx. 1.0-1.5 kg depending on the grain size. Do not overfill the salt container with salt.



ⓘ The water expelled by filling the salt container with salt runs out of the salt container onto the base of the washing compartment. This is not a cause for concern, the water will be pumped out at the start of the next wash programme.

5. Clean any salt remnants on the container opening.

6. Turn the lid clockwise to the stop, otherwise dishwasher salt will leak into the wash water, this could lead to poor wash results. To avoid this run a rinse programme after filling the salt container with special salt. This will wash away salt water and any salt crystals that have been spilt.

ⓘ Depending on the size of the salt grains, it can take several hours for the salt to dissolve in the water and the special salt indicator ⥁ to extinguish. The setting of the water softener and the consumption of salt are dependent on the hardness of the local water.

Downloaded from www.Manualslib.com manuals search engine

Rinse aid

Rinse aid ensures thorough rinsing and spot and streak free drying of dishes and glassware.

Rinse aid can be added in one of two ways:

- If you are using dishwasher detergent that already contains rinse aid, the detergent including the rinse aid is put into the detergent compartment.
  - In this case the dispensing of rinse aid from the dispenser must be **deactivated** to avoid a double dosage.
- If you are using dishwasher detergent and rinse aid separately, the rinse aid is put into the rinse aid dispenser.
  - In this case the dispensing of rinse aid from the dispenser must be **activated.**
  - The amount of rinse aid to be dispensed must be set.

⚠ Only use branded rinse aid specifically designed for dishwashers. Never fill the rinse aid container with any other substance (e.g. concentrated vinegar) or dishwasher detergent. This would damage the appliance.

Activating/deactivating the inflow of rinse aid

ⓘ Some appliances are equipped with an additional **3 in 1** function. If you are using 3-in-1 dishwashing tablets and select the **3 in 1** function together with the wash programme, the inflow of rinse aid does not have to be deactivated (see "**3 in 1** function").

☞ **1.** Press the ON/OFF button.
The ON/OFF button's LED will illuminate.

ⓘ If other indicators are also illuminated, this means that a wash programme has been started. The wash programme must be cancelled (RESET):
Press function buttons **2** and **3** simultaneously for approx. 2 seconds.
All other indicators will go out.

2. Press function buttons **2** and **3** simultaneously and keep them pressed.
The LED indicators for function buttons 1 to 3 will flash.

3. Press function button **2** again.
The LED indicator for function button **2** will flash.

Downloaded from www.Manualslib.com manuals search engine

The →| display will indicate the current setting:

The →| indicator is illuminated:	Rinse aid will be dispensed (ex-factory setting)
The →| indicator is not illuminated:	Rinse aid will not be dispensed

4. Pressing function button **2** activates and deactivates the rinse aid dispensing function.
5. If the rinse aid dispensing function has been correctly set, press the ON/OFF button.
   The setting of the rinse aid dispensing function is now saved.

Adding rinse aid

If you are using dishwasher detergent and rinse aid separately, add the rinse aid:
– Prior to using the dishwasher for the first time
– When the ✳ indicator on the control panel is illuminated.

The rinse aid compartment is on the inside of the dishwasher door.

☞ 1. Open the door.
2. Press the rinse aid compartment release button with your finger.
3. Fully open the rinse aid compartment lid.



Downloaded from www.Manualslib.com manuals search engine

4. Fill with rinse aid exactly up to the level marked "max"; this corresponds to a quantity of approx. 140 ml.
5. Close the lid and press until it locks into place.
6. Wipe up any spilt rinse aid with a cloth. Otherwise too much foam will be formed during the wash.



Adjusting Rinse Aid Dosing

As the dishes are washed rinse aid is released from the dispenser into the wash water. The dose is factory set at 4, and can be adjusted from 1 to 6. Only change the setting if streaks, milky spots or dried on water marks are visible on glasses or crockery.

☞ 1. Open the door of the dishwasher.
2. Press the rinse aid compartment release button with your finger.
3. Fully open the rinse aid compartment lid.
4. Set the dose level.
5. Close the lid and press until it locks into place.
6. If rinse aid has spilt, wipe up with a cloth.



Downloaded from www.Manualslib.com manuals search engine

In Daily Use

- Check the salt and rinse aid levels.
- Load cutlery and dishes into the dishwasher
- Fill with dishwasher detergent
- Select a wash programme suitable for the cutlery and dishes
- Start the wash programme

Loading Cutlery and Dishes

Sponges, household cloths and any object that can absorb water should not be washed in the dishwasher.

For washing in the dishwasher the following cutlery/dishes	
are not suitable:	**are of limited suitability:**
• Cutlery with wooden, horn, china or mother of pearl handles • Plastic items that are not heat resistant • Older cutlery with glued parts that is not temperature resistant • Bonded cutlery items or dishes • Pewter or copper items • Lead crystal glass • Steel items subject to rusting • Wooden platters • Items made from synthetic fibres	• Only wash stoneware in the dishwasher if it is specifically marked as being dishwasher-safe by the manufacturer. • Glazed patterns may fade if machine washed frequently. • Silver and aluminium parts have a tendency to discolour during washing. Left-overs, e.g. egg white, egg yolk and mustard often cause discolouring and staining on silver. Therefore always clean left-overs from silver immediately, if it is not to be washed straight after use. • Some types of glass can become dull after a large number of washes.

- Before loading the dishes, you should:
  - Remove all scraps of food.
  - Soften remnants of burnt food in pans.
- When loading the dishes and cutlery, please note:
  - Dishes and cutlery must not impede the rotation of the spray arms.
  - Load hollow items such as cups, glasses, pans, etc. with the opening downwards so that water cannot collect in the container or a deep base.
  - Dishes and items of cutlery must not lie inside one another, or cover each other
  - To avoid damage to glasses, they must not touch
  - Do not lay small objects (e.g. lids) in the cutlery rack

Downloaded from www.Manualslib.com manuals search engine

Loading Cutlery

⚠ Long bladed knives stored in an upright position are a potential hazard.

⚠ Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.

⚠ Take care when loading or unloading sharp items such as knives.

To ensure that all items of cutlery are completely washed, you should

☞ **1.** Place the grid insert on the cutlery rack

2. Place short knives, forks and spoons in the grid insert with their handles pointing downwards.

3. For larger items of cutlery, e.g. a whisk, half of the top for the cutlery basket can be left off.



On some models of dishwasher it is possible to open the cutlery basket.

⚠ To ensure that the cutlery rack cannot open on removal from the appliance, you should always hold both parts of the two part handle.

☞ **1.** Place the cutlery rack on a table or work surface

2. Open the two part handle

3. Remove cutlery

4. Close the two part handle.



Downloaded from www.Manualslib.com manuals search engine

Loading Pans, Frying Pans and Large Plates

Load large and heavily soiled dishes in the lower basket (Plates up to 29cm in diameter).



Your dishwasher has one of the following four types of lower basket:

Type 1: None of the plate inserts in the lower basket can be removed

Type 2: The right-hand plate inserts in the lower basket can be folded over to the left

To ease the loading of large items, the two right-hand plate inserts in the lower basket can be folded over to the left

1. Slightly lift the right plate inserts.



2. Fold the plate inserts to the left.



Downloaded from www.Manualslib.com manuals search engine

Type 3: The right-hand plate inserts in the lower basket can be folded across one another

To ease the loading of large items, the two right-hand plate inserts in the lower basket can be folded across one another.



Type 4: The two rear plate inserts in the lower basket can be folded across one another

To ease the loading of large items, the two rear plate inserts in the lower baskets can be folded across one another.



Downloaded from www.Manualslib.com manuals search engine

Loading Cups, Glasses and Coffee Services

Load small, delicate items and long pointed cutlery in the upper basket.



- Arrange items of crockery on the folding cups racks so that they are offset from each other and water can reach all items.
- The cup racks can be folded up out of the way for tall items.
- Lay or hang wine, champagne, and brandy glasses in the cut outs on the cup racks.
- Glasses, beakers, etc. can also be placed on the two rows of prongs on the left of the upper basket.



Downloaded from www.Manualslib.com manuals search engine

Adjusting the Height of the Upper Basket

	Maximum Height of the Dishes in the Upper Basket	Lower Basket
With upper basket raised	22 cm	31 cm
With upper basket lowered	24 cm	29 cm

The height of the basket can also be adjusted when it is loaded.

Lowering the Upper Basket:

☞ **1.** Pull the upper basket out completely.

2. Holding the upper basket at the rear right, lift it as far as it will go and then lower it vertically. The upper basket will engage in the lower position.



Raising the Upper Basket:

☞ **1.** Pull the upper basket out completely.

2. Holding the upper basket at the rear right, lift it as far as it will go and then lower it vertically. The upper basket will engage in the higher position.

Downloaded from www.Manualslib.com manuals search engine

Filling with Detergent

Only use dishwasher detergent.

Fill with detergent:

– Prior to the start of a wash programme (not for the pre wash programme). The detergent is released into the wash water during the programme.

Please observe the manufacturer's dosing and storage recommendations as stated on the detergent packaging.

The detergent compartment is on the inside of the dishwasher door.



☞ **1.** If the lid is closed:
press release button (1).
The lid springs open.

2. Fill the detergent dispenser with detergent. The markings indicate the dosing levels:
"20" corresponds to approx. 20 ml of detergent,
"30" corresponds to approx. 30 ml of detergent.

3. Close the lid and press until it locks into place.



If the dishes are very heavily soiled put additional detergent into the adjacent chamber (2). This detergent will take effect during the pre wash.

Downloaded from www.Manualslib.com manuals search engine

Use of "3 in 1"/ Combi Detergent Tablets

General Advice

These products are tablets with combined detergent/rinse-aid and salt functions.

☞ **1.** Before using these products you should first check that the water hardness in your supply is compatible with the use of these products as per the detergent manufacturers instructions (on the product packaging).

2. These products should be strictly used according to the detergent manufacturers instructions.

⚠ **Do not place the tablets in the tub or the cutlery basket as this will result in poorer wash results. The tablets should be placed in the detergent doser.**

3. If you encounter problems when using "3 in1" products for the first time then please contact the detergent manufacturers care line (the telephone number is given on the product packaging).

Special Advice

When using combination products, the rinse-aid and salt lights are no longer useful. It may be helpful therefore to switch the rinse aid off - please note that only some dishwashers have this facility - and selecting the lowest possible setting for water hardness.

For more information please refer to your instruction manual.

If you decide to switch to the use of a standard detergent system we advise that you:

- Refill both the salt and rinse aid compartments.
- Switch the waterhardness setting to the highest possible position and run for three normal cycles without a load.
- Readjust the waterhardness setting again according to the conditions for your region (as per the instruction manual).

Downloaded from www.Manualslib.com manuals search engine

Concentrated Detergent

Based on their chemical composition, dishwasher detergents can be split into two basic types:
- **conventional**, alkaline **detergents** with caustic components
- low alkaline **concentrated detergents** with natural enzymes.

The use of 50 °C wash programmes in conjunction with concentrated detergents reduces pollution and is good for your dishes; these wash programmes are specially matched to the dirt-dissolving properties of the enzymes in the concentrated detergent. For this reason 50 °C wash programmes in which concentrated detergents are used can achieve the same results that can otherwise only be achieved using 65 °C programmes.

Detergent tablets

Detergent tablets of different makes dissolve at different speeds. For this reason some detergent tablets cannot develop their full cleaning power during short programmes. Therefore please use wash programmes with pre wash when using detergent tablets.

Downloaded from www.Manualslib.com manuals search engine

Selecting the Wash Programme (Programme Table)

Choose the most suitable wash programme with the aid of this table:

Type of Dishes	Dinner Service and Cooking Utensils	Dinner Service and Cooking Utensils	Coffee Service and Dessert Dishes	All Types of Dishes
In Addition	-	with non temperature resistant dishes		-
Type of Soiling	• heavily soiled • dried on left-overs, particularly egg white and thickeners	• average soiled particularly suitable when concentrated detergents are used.	• average to slightly soiled •	Used dishes that are collected in the dishwasher and are to be washed at a later point in time.
Suitable Programme:	INTENSIV 70°	NORMAL 50°	ECO 50° [1] [2]	
Programme Sequence [3]	Pre wash Main wash 2x Rinsing Final rinse Drying	Pre wash Main wash Rinsing Final rinse Drying-	Pre wash Main wash Rinsing Final rinse Drying	Pre Wash - - - -
Consumption Figures: [4]	⇩	⇩	⇩	⇩
Duration	110 - 120 min.	85 - 95 min.	130 - 150 min.	12 minutes
Energy	1,75 - 1,95kWh	1,10 - 1,20 kWh	0,95 - 1,05 kWh	< 0.1 kWh
Water	22 - 24litres	14 - 16 litres	13 - 15 litres	4 litres

1) Test programme for test institutes
2) The **ECO 50°** wash programme washes normally soiled dishes with a very low electricity consumption. If the dishes need to be washed more quickly, as an alternative you can use the **NORMAL 50°** wash programme.
3) Noise levels vary at different stages of the wash programme as at some programme stages the dishes are washed more energetically so that they will be cleaned more thoroughly.
4) The consumption figures were determined under standard conditions. They are intended as a guide only and depend on the loading. For this reason figures may vary in practice.

Downloaded from www.Manualslib.com manuals search engine

Starting a wash programme

☞ **1.** Check that the dishes and cutlery are stacked in the dishwasher in such a way that the spray arms are free to rotate.

2. Turn on the water tap fully.

3. Close the door.

4. Press the ON/OFF button.
The LED in the ON/OFF button will illuminate.

5. Press the relevant button for the programme required (see "Programme Table").
The programme display will illuminate. One or two lights will flash in the programme progress display.
The selected programme will begin after approximately 3 seconds.

i If →| flashes in the programme progress display after the programme has started, please read the section "What to do if...".

Changing / interrupting / cancelling a wash programme

i Only change or interrupt a wash programme that is in progress if it is absolutely necessary. After the appliance door has been closed again, the air that has entered will be heated significantly and expand. As a result, water may collect in the base of the appliance and trigger the anti-flood system.

Changing a wash programme

i If you would like to change the wash programme in the first 3 seconds after having selected a programme, press the button for the new wash programme.

If you would like to change the wash programme after this time, proceed as follows:

☞ **1.** Press the button for the new wash programme and hold it down.
First, the indicator for the wash programme that is currently running will flash.
After several seconds only the indicator for the new wash programme will be illuminated.

2. Release the programme button.
The newly selected wash programme will begin.

Downloaded from www.Manualslib.com manuals search engine

Interrupting the wash programme by opening the dishwasher door

⚠ Hot steam may escape when the door is opened. There is a risk of scalding. Open the door carefully.

☞ **1.** Open the door of the dishwasher.
The wash programme will stop.

2. Close the door.
The wash programme will continue.

Cancelling the wash programme (RESET)

☞ **1.** Press function buttons **2** and **3** and keep them pressed.
The programme display for the current wash programme will flash for several seconds and then go out.

2. Release the function buttons.
The wash programme has been cancelled.

ℹ Turning off the dishwasher will only interrupt a selected wash programme, not cancel it. The wash programme will recommence after turning the dishwasher back on again.

Setting or changing the start delay

Using the start delay you can set whether a wash programme is to begin in 3, 6 or 9 hours.

Setting the start delay:

☞ **1.** Press the ON/OFF button.

2. Press the ⏲ start delay button until the indicator next to the number of hours until the wash programme starts is illuminated.

3. Press the button for the desired wash programme.
The LED indicator for the programme selected and the indicator next to the number of hours will illuminate.
The wash programme will start automatically following a countdown of the hours set.

Changing the start delay:

As long as the wash programme has not yet started, you can change the start delay set by pressing the START DELAY button.

Cancelling the start delay:

As long as the wash programme has not yet started, you can cancel the start delay. Press the START DELAY button until none of the three time displays are illuminated. The selected wash programme will begin immediately.

Downloaded from www.Manualslib.com manuals search engine

Changing the wash programme after the start delay has been set:
As long as the wash programme has not yet started, you are able to change the programme set by pressing a wash programme button.

☞ **1.** Press the button for the new wash programme and hold it down.
First, the indicator for the wash programme that was already selected will flash.
After several seconds only the indicator for the new wash programme will be illuminated.

2. Release the programme button.
The wash programme will start automatically following a countdown of the hours set.

Load Sensing – Sensor Logic

If a wash programme is started even though there are only a few dishes in the upper and/or lower basket, an intelligent electronic system adjusts the amount of water and the duration of the wash programme to the number of dishes. By this means it is possible to wash only a few dishes quickly and economically. At half load (6 place settings), up to 2 litres of water and 0.2 kWh of electricity are saved.

Switching Off the Dishwasher

Switch off the dishwasher when →| is illuminated on the programme progress display.

☞ **1.** Press the ON/OFF button.
The ON/OFF button indicator extinguishes.

⚠ Hot steam may escape from the appliance when opening the door immediately after the end of the programme.

2. Open the door carefully.

Emptying the Dishwasher

ⓘ
- The dishes should therefore be allowed to cool down before removing them from the appliance, as hot dishes may be sensitive to knocks.
- Leave the dishes in the dishwasher for approx. 15 minutes after the end of the programme so that they dry better and can cool down.
- First empty the lower basket, and then the upper basket. This will avoid any water that may be remaining in the upper basket, dripping onto the dishes in the lower basket and leaving water marks.

Downloaded from www.Manualslib.com manuals search engine

Care and Cleaning

Do not under any circumstances use furniture care products or aggressive cleaners.

- If necessary, clean the controls only with a soft cloth and pure warm water.
- Occasionally check the internal containers, door seal, and water inlet for soiling, clean if necessary.

Cleaning the Filter

The filters should be checked and cleaned regularly. Dirty filters will give poor wash results.

1. Open the door, remove the lower basket.
2. The dishwasher filter system comprises a coarse/fine filter, microfilter and a flat filter. Unlock the filter system using the handle on the microfilter, and remove.
3. Turn the handle about ¼ a turn anticlockwise and remove.
4. Take hold of the coarse/fine filter (1/2) by the handle with the hole and remove from the microfilter (3)
5. Clean all filters thoroughly under running water.
6. Remove the flat filter (4) from the base of the washing compartment and clean both faces thoroughly





Downloaded from www.Manualslib.com manuals search engine

7. Put the flat filter back in the base of the washing compartment
8. Place the coarse/fine filter in the microfilter and press together.
9. Put the filter combination in place and lock by turning the handle clockwise to the stop. During this process ensure that the flat filter does not protrude above the base of the washing compartment.



⚠ The dishwasher must not be used without filters under any circumstances.

Downloaded from www.Manualslib.com manuals search engine

What to do, if ...

Try to rectify minor faults on the dishwasher with the aid of the instructions given here. If you call an engineer to resolve a of fault listed here, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is in guarantee.

...Error messages are displayed.

If any of the indicators in the control panel, as listed in the table below, are flashing or are illuminated, you can probably rectify the fault yourself.

Malfunction	Possible cause	Remedy
The programme indicator for the selected wash programme is flashing; the end wash programme indicator is flashing in **the following sequence: 1** short flash with approx. 3 seconds pause in between: There is no water entering the dishwasher.	The tap is blocked or furred with lime-scale	Clean the tap
	The tap is turned off.	Turn the tap on.
	The filter (where present) in the threaded hose fitting on the tap is blocked.	Clean the filter in the threaded hose fitting.
	Filters in the base of the washing compartment are blocked.	Press the button for the wash programme that had already started; then cancel the wash programme by pressing RESET (see chapter: Starting a wash programme); Clean out the filters. (See chapter: Cleaning the filters)
	The water inlet hose has not been correctly laid.	Check hose installation.

Downloaded from www.Manualslib.com manuals search engine

Malfunction	Possible cause	Remedy
The programme indicator for the selected wash programme is flashing, the end wash programme indicator is flashing in the following **sequence: 2** short flashes one after the other.	The siphon is blocked.	Clean out siphon.
	The water drain hose has not been correctly laid.	Check hose installation.
The end wash programme indicator is flashing in the following **sequence: 3** short flashes, one after the other.	The leak prevention system has been triggered.	Turn off the tap and contact customer service.

After remedying the error that is flashing in the **first or second sequence** in the programme progress display, press the button for the wash programme that had already started. The wash programme will continue.
If the fault is displayed again, please contact your local Service Force Centre.

For all other errors displayed, please contact Service Force, stating the error code. (See chapter "Customer Service").

Downloaded from www.Manualslib.com manuals search engine

...there are problems with the operation of the dishwasher.

Symptom	Possible Cause	Solution
The programme does not start.	The door of the dishwasher is not closed properly.	Shut the door.
	Mains plug is not plugged in.	Insert mains plug.
	House fuse is defective.	Replace fuse.
	A start delay is selected.	If dishes are to be washed immediately cancel delay start timer.
Rust spots are visible in the washing compartment.	The washing compartment is made from rust-free stainless steel. Rust spots in the washing compartment are due to rust particles from external sources (rust particles from water pipes, pans, cutlery, etc.). Remove such spots with one of the stainless steel cleaners that are generally available on the market.	Only wash cutlery and dishes that are suitable for dishwasher use.
		Close the lid of the special salt container securely.
There is a whistling noise during washing.	The whistling is not a cause for concern.	Use a different brand of detergent.

...the wash results are not satisfactory.

The dishes are still dirty.

- The wrong wash programme was selected.
- The dishes were loaded is such a way that the wash waster did not reach all items. The baskets for the dishes must not be overloaded.
- The filter in the base of the washing compartment is dirty or incorrectly positioned.
- Detergent was not used or too little was used.
- In the case of scale deposits on the dishes: The special salt container is empty or the water softener is incorrectly adjusted.
- The drain hose is incorrectly laid.

Downloaded from www.Manualslib.com manuals search engine

The dishes are wet and dull.
- Rinse aid was not used.
- The rinse aid container is empty.

There are streaks, milky spots or a bluish coating on glasses and dishes.
- Lower rinse aid dosing.

There are dried water drops on the glasses and dishes.
- Increase rinse aid dosing.
- The detergent may be the cause. Contact the detergent manufacturer's customer advisor.

Technical Data

Capacity:	12 place settings including serving dishes
Permitted Water Pressure:	1-10 bar (=10-100 N/cm^2 = 0.1-1.0 MPa)
Electrical Connection:	Information on the electrical connection is given on the rating plate on the inner edge of the dishwasher door on the right.
Dishwasher: Free-Standing Appliances	
Dimensions:	850 x 600 x 600 (H x W x D in mm)
Max. Weight:	54 Kg
Dishwashers that Can Be Integrated, Built-In Dishwashers	
Dimensions:	820 – 880 x 596 x 570 (H x W x D in mm)
Max. Weight:	50 Kg
Dishwashers that Can Be Fully Integrated	
Dimensions:	820 – 880 x 596 x 546 - 550 (H x W x D in mm)
Max. Weight:	50 Kg

CE This appliance conforms with the following EU Directives:
- 73/23/EWG dated 19. 02. 1973 – Low Voltage Directive
- 89/336/EWG dated 03. 05. 1989 (including Directive Amendment 92/31/EWG) – EMC Directive

Downloaded from www.Manualslib.com manuals search engine

Notes for Test Institutes

Testing in accordance with EN 60704 must be carried out with the appliance fully loaded and using the test programme (see Programme Table).

Tests in accordance with EN 50242 must be carried out when the salt dispenser and rinse aid container have been filled with salt and rinse aid respectively and using the test programme (see Programme Table).

	Full Load: 12 place settings incl. serving dishes	Half Load: 6 place settings incl. serving dishes, leaving alternate positions free
Detergent Dosing:	5g + 25g (Type B)	20g (Type B)
Rinse Aid Setting:	4 (Type III)	4 (Type III)

Sample loading arrangements:

Upper basket *





* If necessary, move the cup rest from right to left. When doing this, ensure that the cup rest is at the same height.

Lower basket with cutlery basket



Cutlery basket



Downloaded from www.Manualslib.com manuals search engine

INSTALLATION AND CONNECTION INSTRUCTIONS

Installing the Dishwasher

- The dishwasher must be installed on a firm floor and adjusted such that it is stable and level.
- To compensate for unevenness in the floor and to match the height of the appliance to that of surrounding units extend the threaded feet by unscrewing:
  – use a screwdriver.



- For built-in dishwashers the rear feet should be adjusted from the front of the appliance using a screwdriver.
- The drain hose, inlet hose and mains cable must be laid such that they are free to move in the rear of the plinth recess, so that they cannot be kinked or crushed.

Built-Under Dishwasher

(see enclosed installation instructions)

Free-Standing Appliances

can be set up as stand-alone without additional installation.

⚠ If the dishwasher is set up next to a gas or coal cooker, a heat-insulating, non-flammable plate must be mounted between the dishwasher and the cooker, flush to the top edge of the work surface (depth 57.5 cm). The plate should have aluminium foil on the side facing the cooker.

Downloaded from www.Manualslib.com manuals search engine

If the dishwasher is installed underneath a kitchen work surface, the original work surface of the dishwasher is to be removed as follows:

☞ **1.** Unscrew the screws from the positioning plates on the back (1).



2. Slide the appliance's work surface approx. 1 cm to the rear (2).



3. Lift the work surface at the front (3) and remove.



⚠ If the dishwasher is later used as a free-standing appliance, the original work surface must be re-mounted.

ℹ The plinth on free-standing appliances is not adjustable.

Downloaded from www.Manualslib.com manuals search engine

Connecting the Dishwasher

Water Connection

The dishwasher is fitted with safety devices that prevent the wash water returning into the drinking water system and comply with the applicable plumbing regulations.

- The dishwasher must be connected to a cold water supply.
- The dishwasher **must not** be connected to open hot water appliances or instantaneous water heaters.

Permitted water pressure

Lowest permitted water pressure: 1 bar (=10 N/cm^2 =100 kPa)	Consult your installer if the water pressure is less than 1 bar.
Highest permitted water pressure: 10 bar (=100 N/cm^2 =1 MPa)	In the case of a water pressure greater than 10 bar, a pressure reduction valve must be used (available from your dealer).

Connect the inlet hose

The water inlet hose must not be kinked, crushed or entangled when it is being connected up.

Connect the threaded hose fitting (ISO 228-1:2000) on the water inlet hose to a tap with an external thread (¾ inch). The inlet hose is equipped either with a plastic or with a metal connection nut:
- **Tighten plastic** hose connection nuts **by hand** only.
- **Metal** hose connection nuts **must be tightened using an appropriate tool**. Finally, visually check that it is water-tight (ensure that the tap is not dripping).

- In order that access to the tap in the kitchen is not limited by the use of the dishwasher, we recommend the installation of an additional tap, or fitting a two way adapter to the existing tap.
- If you need a longer water inlet hose than that supplied, VDE approved complete hose sets are to be used. These are available from your local Service Force Centre.
- Do not use, for connection, old hoses which have been used for another appliance.

Downloaded from www.Manualslib.com manuals search engine

The following section is only applicable to dishwashers that have a safety valve on the threaded hose fitting for the tap:

Water inlet hose with safety valve

After connecting the double-walled water inlet hose, the safety valve is next to the tap. Therefore the water inlet hose is only under pressure while the water is running. If the water inlet hose starts to leak during this operation, the safety valve cuts off the running water and the draining pump in the dishwasher is switched on.

Please take care when installing the water inlet hose:

- The distance between the bottom edge of the safety value and the floor on which the dishwasher is standing must be at least 30 cm:
- The electrical cable for the safety valve is in the double-walled water inlet hose. Do not immerse the water inlet hose or the safety valve in water.
- If the water inlet hose or the safety valve is damaged, remove the mains plug immediately.
- A water inlet hose with safety valve must only be replaced by your local Service Force Centre.



- Place the water inlet hose in such a way that it is never higher than the bottom edge of the safety valve.



Downloaded from www.Manualslib.com manuals search engine

Water drain

Drain hose

The drain hose must not be kinked, crushed or entangled.

- Connecting the drain hose:
  - Maximum permitted height: 1 metre.
  - Minimum required height 40 cm above the lower edge of the machine.

Extension hoses

- Extension hoses are available from AEG Service Force. The internal diameter of the extension hoses must be 19 mm to ensure that the function of the appliance is not impeded.
- Hoses may be laid a maximum of 3 metres horizontally; the maximum permitted height for the connection for the drain hose is then 85 cm.



Sink outlet connection

- The outlet of the drain hose (ø 19 mm) fits all commonly available sink outlet spigot types. The outer diameter of the spigot connection must be at least 15 mm.
- The drain hose must be fixed to the sink outlet connection using the hose clamp supplied.

If the dishwasher is fitted at a high position

If the dishwasher is installed at a high level, and the drainhose connection is less than 30 cm from the bottom of the appliance, adapter kit ET 111099520 must be fitted. This is available from Customer Service.

Discharging into a standpipe

When discharging into a standpipe, the upright standpipe should have a minimum, length of 30 cm (12") from the bottom of the elbow to the top of the pipe (see diagram). Make sure that it is designed in such a way that the end of the drain hose cannot be covered with water.



Downloaded from www.Manualslib.com manuals search engine

Leak Prevention System

For protection from damage due to water leaks, the dishwasher is equipped with a leak prevention system, the AQUA CONTROL SYSTEM. In the event of a fault, the safety valve in the appliance immediately interrupts the inflow of water and the drain pump is activated. By this means water can neither escape nor overflow. The remaining water in the appliance is automatically pumped out.

The leak prevention system also works when the appliance is switched off, the appliance must however not be disconnected from the mains.

Downloaded from www.Manualslib.com manuals search engine

Electrical Connection

Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

WARNING - This appliance must be earthed.
The manufacturer declines any responsibility should these safety measures not be observed.

Before switching on make sure the electricity supply voltage is the same as that indicated on the appliance rating plate.

To isolate the dishwasher from the mains, remove the mains plug.
Important: The plug must still be accessible after the appliance has been installed.

Changing a fuse

The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS 1363A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires on the mains lead are coloured in accordance with the following code.

Green and Yellow : Earth
Blue : Neutral
Brown : Live



- The wire coloured green and yellow must be connected to the terminal marked with the letter "E" or by the earth symbol ⏚ or coloured green and yellow.
- The wire coloured blue must be connected to the terminal "N" or coloured black.
- The wire coloured brown must be connected to the terminal marked "L" or coloured red.
- Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.

WARNING! A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that, if it is necessary to cut off the plug, it is disposed of safely and not retained.

Downloaded from www.Manualslib.com manuals search engine

Connections

The water inlet and drain hoses, as well as the mains cable must be connected beside the dishwasher as there is insufficient space behind the appliance.

The plumbing and electrical installation example given below can only be regarded as a recommendation.



Downloaded from www.Manualslib.com manuals search engine

GUARANTEE CONDITIONS

Standard guarantee conditions

We, AEG, undertake that if within 12 months of the date of the purchase this AEG appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our discretion repair or replace the same FREE OF CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity or gas supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's operating and maintenance instructions.
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with by any person not authorised by us.
- All service work under this guarantee must be undertaken by a Service Force Centre. Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.
- Home visits are made between 8.30am and 5.30pm Monday to Friday. Visits may be available outside these hours in which case a premium will be charged.

Exclusions

This guarantee does not cover:

- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of AEG manufacture which are not marketed by AEG.

European Guarantee

If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

- The guarantee starts from the date you first purchased your product.
- The guarantee is for the same period and to the same extent for labour and parts as exists in the new country of use for this brand or range of products.
- This guarantee relates to you and cannot be transferred to another user.
- Your new home is within the European Community (EC) or European Free Trade Area.
- The product is installed and used in accordance with our instructions and is only used domestically, i.e. a normal household.
- The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliances..

France	Senlis	+33 (0) 3 44 62 29 29
Germany	Nürnberg	+49 (0) 800 234 7378
Italy	Pordenone	+39 (0) 800 117511
Sweden	Stockholm	+46 (0) 8 672 5360
UK	Slough	+44 (0) 1753 219899

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

SERVICE AND SPARE PARTS

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact Service Force by telephoning:

08705 929 929

Your telephone call will be automatically routed to the Service Force Centre covering your post code area.
For the address of your local Service Force Centre and further information about Service Force, please visit the website at www.serviceforce.co.uk

Before calling out an engineer, please ensure you have read the details under the heading „What to do if....."

When you contact the Service Force Centre you will need to give the following details:

1. Your name, address and post code.
2. Your telephone number
3. Clear and concise details of the fault.
4. The model and serial number of the appliance (found on the rating plate).



5. The purchase date

Please note that a valid purchase receipt or guarantee documentation is required for in-guarantee service calls.

Customer Care

For general enquiries concerning your AEG appliance or for further information on AEG products please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.aeg.co.uk.

Customer Care Department
AEG Domestic Appliances
55-77 High Street
Slough
Berkshire, SL1 1DZ

Tel. 08705 350350 (*)

(*) Calls may be recorded for training purposes

Downloaded from www.Manualslib.com manuals search engine

From the Electrolux Group. The world's No.1 choice.

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.

AEG Hausgeräte GmbH
Postfach 1036
D-90327 Nürnberg

http://www.aeg.hausgeraete.de

© Copyright by AEG

822 961 070 -00- 0603

Subject to change without notice

Downloaded from www.Manualslib.com manuals search engine